



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – Chrome Plated Freeway Bar
- 1 – Horn Relocator Bracket
- 3 – Polished Button Head Bolts

Application(s) >

- KAWASAKI VN1500P MEAN STREAK 02-03
- KAWASAKI VN1600B 04-08
- SUZUKI MARAUDER 1600 2004

Instruction Manual >

01-1460

Page 1 of 1

Read all directions carefully before installing your Cobra freeway bar

1. Disconnect horn and remove it by taking the two 6mm bolts that mount it to the frame out. Keep the bolts for later use.
2. Remove the front bottom bolt from each of the foot peg mounts where it bolts to the frame. Keep the bolts for later use.
3. Mount the Cobra freeway bar to the foot peg mount using the stock bolts removed in step 2 and finger tighten only. **Note:** Freeway bar brackets will be on the outside of the foot peg mounts.
4. Line up top bracket of Cobra freeway bar with the horn mounting tab on the frame, secure using stock 6mm bolts removed in step 1.
5. Locate the small hole in the frame gusset on the left side of the vehicle, just in front of the gas tank.
6. On the horn relocator bracket place the end with one hole behind the frame gusset at an angle of about 45 degree's and secure with one of the supplied button head bolts. **Note:** Bracket smooth side should be facing out with the threaded pem nut to the back.
7. Mount the horn to the outside of relocator bracket using the two remaining button head bolts. Re-route the horn wires and plug them back on to the horn.
8. Tighten all mounting bolts to factory specifications before riding vehicle.

* *Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0017

REV. A

12/02

Anything's Possible.