

Items Supplied >

- 1 – 18" Wire With Push On Terminal
- 1 – Push On Connector
- 1 – Blue Quick Splice Connector
- 1 – Light Bar Assy. W/Turn Signals

Application(s) >

VLX600 99-06

Instruction Manual >

04-0101

Page 1 of 1

Read your installation instructions completely before beginning. This light bar can be installed in just a few minutes using common tools. It is recommended however, that a qualified mechanic or technician install this product.

1. Your Boulevard Light Bar comes with everything you need to mount and wire it to your motorcycle. After unpacking the light bar, you will need to turn the spot lights around 180 degrees, they are facing backwards for packaging purposes only.
2. Remove the plastic covers just in front of the gas tank and disconnect the turn signals
3. Remove both turn signals from the fork legs.
4. Remove the entire headlight assembly by removing the two (2) nuts underneath the lower triple clamp. Install your Boulevard Products Light Bar in between the triple clamp and the headlight assembly. Align the headlight and light bar assembly and tighten the two nuts to factory torque specs. Align the turn signals and spotlights. Check to make sure the screws on top of the light bar frame that hold the black injection molded turn signal mounts are snug.
5. Connect the 20" wire to one of the poles on the switch. It doesn't matter which one. Route the other end of the wire the same way the turn signal wires were routed and connect them to a power supply wire using a quick splice.
6. Twist the ends of the two spotlights together and insert them into the supplied push on connector and crimp with a wire crimp tool. Connect this wire to the other pole on your light bar switch.
7. Plug your new turn signal wires into the locations that the original ones were installed using the chart bellow. Reinstall the plastic covers removed in step 2.
8. **Check to make sure that the handlebars turn "lock to lock" without any stretching or binding of the wires.** Check the alignment of all the lighting; make sure everything is working properly before riding.

WIRING CHART

Application	Motorcycle	Light Bar
Ground	Green	Black/Yellow
Turn Indicator Left	Orange	Blue
Running Light Left	Orange/White	Gray
Turn Indicator Right	Lt. Blue	Blue
Running Light Right	Lt. Blue/White	Gray

*** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**