

Items Supplied >

- 1 - Right Rider Floorboard Assembly
- 1 - Left Rider Floorboard Assembly
- 2 - M8 Bolts
- 2 - Nuts

Application(s) >

- GOLDWING 1500 90-97
- VALKYRIE 97-02
- VALKYRIE TOURER 98-00
- VALKYRIE INTERSTATE 98-01

Instruction Manual >

06-1640/06-4140

Page 1 of 1

This product installation requires adjusting the brake pedal and gear shifter. Read all instructions carefully and completely before installing your new Boulevard Products Floor Boards.

1. Remove the 6mm Allen bolt and the chrome cover above the right side footpeg assembly. Remove the bolts attaching the master cylinder behind the chrome cover.
2. Remove your right side footpeg from the motorcycle. Install the right floorboard assembly into the footpeg mount on the frame using the supplied 8mm x 40mm bolt and nylock nut. The nut should be on the bottom of the mount.
3. Reinstall the master cylinder in its original position using the stock hardware.
4. Adjust the rear brake pedal by loosening the lock nut next to the clevis and turning the nut on the master cylinder shaft out approximately 2 1/2 turns. Sit on the bike and check to make sure that your brake pedal can be depressed from the riding position. Once adjusted properly, tighten the securing nut on the adjuster.
5. Install the chrome cover back into its original position.
6. Remove the left side footpeg from the motorcycle. Install the left floorboard assembly into the footpeg mount on the frame using the supplied 8mm x 40mm bolt and nylock nut.
7. Prior to adjusting the position of your gearshift lever, note its location on its pivot shaft. Loosen the bolt that holds it onto its shaft. Remove the shifter and rotate it up two splines of the shaft. Tighten the bolt that secures the lever.
8. Make sure you can operate both the gearshift lever and the rear brake lever effectively prior to riding the motorcycle. Your motorcycle will have a different feel than before. Be careful until you get used to it.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*