

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 2 - 6mm x 35mm B.H.C.S
- 2 - 6mm Nylock Hex Nuts
- 4 - 6mm Flat Washers
- 2 - Sets Of Floorboards And Mounts

Application(s) >

HONDA SPIRIT 750-C2	07-14
HONDA AERO 750	04-14
HONDA PHANTOM 750	10-14

Instruction Manual >

06-3611B / 06-4611B

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove the two bolts on each side of your motorcycle that mount the passenger pegs to the frame.
2. Install the passenger floorboard assemblies into these locations using the supplied hardware. Torque to factory specification.

To clean your black accessory use a liquid based soap detergent, such as dishwashing soap applied with a soft cloth and rinse with clean water. Note: Avoid abrasive cleaning methods such as granular or dry cleansers, simple green, Scotch-Brite or steel wool pads. Abrasives may breach the coating and shorten life.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***



® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 2 - 6mm x 35mm B.H.C.S
- 2 - 6mm Nylock Hex Nuts
- 4 - 6mm Flat Washers
- 2 - Sets Of Floorboards And Mounts

Application(s) >

HONDA SPIRIT 750-C2	07-14
HONDA AERO 750	04-14
HONDA PHANTOM 750	10-14

Instruction Manual >

06-3611B / 06-4611B

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove the two bolts on each side of your motorcycle that mount the passenger pegs to the frame.
2. Install the passenger floorboard assemblies into these locations using the supplied hardware. Torque to factory specification.

To clean your black accessory use a liquid based soap detergent, such as dishwashing soap applied with a soft cloth and rinse with clean water. Note: Avoid abrasive cleaning methods such as granular or dry cleansers, simple green, Scotch-Brite or steel wool pads. Abrasives may breach the coating and shorten life.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***