

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 2 - FLOORBOARD ASSEMBLIES WITH MOUNTS
- 2 - 8mm x 45mm HEX FLANGE BOLTS
- 2 - 8mm NYLOCK NUTS
- 2 - WASHERS

Application(s) >

KAWASAKI VN1700 CLASSIC/LT 09-13

Instruction Manual >

06-3965 / 06-4965

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove your original passenger foot pegs from their mounts.
2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied 8mm bolts, washers and nylock nuts. **NOTE:** An "L" has been engraved on the backside of the left mount to avoid confusion between left and right mounts during installation.
3. Check to make sure that all hardware is properly installed and the bolts are tight prior to riding the motorcycle.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
04/09

Anything's Possible®

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 2 - FLOORBOARD ASSEMBLIES WITH MOUNTS
- 2 - 8mm x 45mm HEX FLANGE BOLTS
- 2 - 8mm NYLOCK NUTS
- 2 - WASHERS

Application(s) >

KAWASAKI VN1700 CLASSIC/LT 09-13

Instruction Manual >

06-3965 / 06-4965

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove your original passenger foot pegs from their mounts.
2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied 8mm bolts, washers and nylock nuts. **NOTE:** An "L" has been engraved on the backside of the left mount to avoid confusion between left and right mounts during installation.
3. Check to make sure that all hardware is properly installed and the bolts are tight prior to riding the motorcycle.

**Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
04/09

Anything's Possible®