

INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES SEATS FOR VICTORY 2006-UP VEGAS JACKPOT MODELS

ATTENTION INSTALLER (if other than owner): Please forward this Instruction Sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing Drag Specialties seats on Victory Vegas Jackpot models. Review these instructions carefully before beginning as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

WARNING!: A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

SOLAR REFLECTIVE TECHNOLOGY:

Solar Reflective Leather keeps the seating area cool even in direct sunlight. The process has been shown to reduce surface temperatures by as much as 25°F.

NOTE: The Solar Reflective Technology is only available on select models. See catalog for specific applications.

CAUTION: The use of leather conditioners or chemicals will void the warranty.

Cleanup: Warm water, mild soap and soft cloth should be used for cleanup.

TOOLS REQUIRED:

6mm Allen wrench socket and ratchet
5mm Allen wrench

REMOVING PASSENGER SEAT

1. Begin by placing the bike on a side stand.
2. Remove the cap at the rear of the seat. Using the 6mm Allen wrench, remove the screw under the cap. Lift the rear of the seat and slide rearward to move.

REMOVING FRONT SEAT

3. Remove both of the fender rail covers using the 6mm Allen socket.
4. Remove the two socket head screws securing the seat. There is one screw on each side.



5. Lift the rear of the seat upward and pull back to disengage the front bracket; remove the seat.
6. Remove the two screws from the front of the chrome passenger seat support using the 6mm Allen socket and remove the support.

INSTALLING YOUR NEW SEAT

7. Locate the front tongue and the two side brackets on the bottom of your new seat. Install the seat by raising the rear slightly while engaging the front tongue into the seat bracket at the rear of the fuel tank while aligning the side mounts along the frame.
8. Align screw holes at sides and rear. Install the two socket head screws (one at each side) that were removed in Step 4 and install the 8 x 20 button head screw provided in the rear seat mount. Torque the rear screw to 12 ft-lb. and the side screws to 18 ft-lb.
9. Reinstall the frame rail covers and torque to 18 ft-lb.

WARNING!: Periodically check and re-torque all fasteners



3501 Kennedy Rd, PO Box 5222, Janesville, WI 53547-5222
P/N 010914