

INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES MINI-GAUGE TACHOMETER MOUNT FOR 96-12 XL/FXD MODELS P/N 2211-0118

ATTENTION INSTALLER (if other than owner): Please forward this Instruction sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing the Mini-Gauge Tachometer Mount on 96-12 XL & FXD models with single-gauge handlebar-mounted speedometer (except 883C & 1200C models). Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

WARNING!: A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

INCLUDED COMPONENTS:

Gauge mounting plate 1
Rubber grommet plug 1
Mounting screws 1
Acorn nuts 2
Tapered spacers 2

PROCEDURE:

1. Disconnect the negative battery cable.
2. Remove the backing plate on the speedometer by removing the two flat-head screws.
3. Install the rubber plug included with the gauge mount. It should go into the hole on the mounting bracket opposite where the reset button sticks out of the backing plate.
4. Install the Odometer Reset Button Rubber Boot in the mounting bracket plate.
5. Install the new gauge mount to the back of the speedometer. Orientate the gauge mount so that the tachometer will sit to the right of the speedometer.
6. Make sure that the U-shaped slot faced down on the gauge mount when installed.
7. Wire in the tachometer according to the instructions included with the tachometer being used.

NOTE: We suggest that all wires be soldered and covered with heat shrink tubing for best reliability.



8. Set the tachometer onto the gauge mount. The gauge mount has additional holes in it for clearance for various gauges.
9. Install the two tapered spacers onto the studs from the tachometer and use the two black acorn nuts. Tighten snugly.

NOTE: The spacers are the correct length for the p/n 2211-0117 tachometer. If used with other Mini-Gauge tachometers, the spacer length may have to be modified, depending on the stud length on the back of the tachometer.

10. Reconnect the negative battery cable and test run the engine, observing that the tachometer behaves as expected.

