

## INSTRUCTION SHEET



### NAVBAG

#### INCLUDED IN BOX:

- (1) NAVBag
- (1) Pre-cut foam trim sized for iPhone
- (1) Pre-cut foam trim sized for Zumo 660
- (1) Plain foam pad for cut-to-fit options  
(other GPS, cell phone, MP3, etc.)
- (1) Foam adjustment block

#### NOTE:

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Klock Werks will not ensure a warranty on components lost due to improper installation. Periodic maintenance may be required.

#### QUESTIONS?

 **EMAIL:**  
info@getklocked.com

 **CALL:** (605) 996.3700

\* This kit includes pre-cut trim for an iPhone and a Zumo 660. The plain foam pad is a cut-to-fit option for any other device. When you trim the piece, make sure it fits tightly around the unit being used. We recommend using either the whole uncut foam pad, or the center piece that was removed, as a backer between the device and velcro strap for added stability.

\* Included in this kit is an adjustment block, which may be needed to set the proper screen angle based on rider height. After installing the NAVBag, place the block on the inner fairing under the bag bottom to set the correct height, if needed.

#### FOR BATWING FAIRING

1. Remove center windshield screw
2. Loosen both outside windshield screws
3. Install NAVBag between inner fairing and windshield
4. Torque screws to 25 in-lbs

#### FOR OE REPLACEMENT

1. Remove the top center bolt from the windshield bracket
2. Insert supplied screw through the top center hole
3. Install NAVBag onto screw from the inside of the windshield
4. Install the supplied bracket onto the screw as shown in **Figure 1**
5. Install the supplied washer and nut and torque to 50 in-lbs



FIGURE 1

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.