INSTRUCTION SHEET

# **MENTELE BARS** FOR FLHR AND CUSTOM APPLICATIONS

**INCLUDED IN BOX:**
Mentele Bars
Instruction Sheet

**NOTE:**
Always refer to model appropriate service manual for procedures and torque specifications

**QUESTIONS?**
**EMAIL:** info@getklocked.com
**CALL:** (605) 996.3700

**Note:** Check cable lengths for proper fit, longer cables may be needed as well as having switch wires extended
Protect painted surfaces

## FOR FLHR APPLICATIONS:

1. Remove the seat and disconnect the negative battery terminal
2. Remove the headlamp
3. Remove right and left nacelle halves
   - **a.** Remove the top spear trim
   - **b.** Remove the handlebar clamp cover
   - **c.** Remove the four nacelle fasteners
4. Remove the clutch and front brake controls from the stock handlebar
5. Remove the switch housings from the stock handlebar and disassemble the wiring connectors
6. Carefully loosen the four handlebar clamp screws and remove the stock handlebars
7. Install your new Mentele handlebars in the handlebar clamp
8. Guide the switch wires through the bars until the switch housings are fully seated and reassemble the connectors
9. Reinstall all components according to service manual procedures and torques specifications.
10. Check steering head from right to left lock to ensure no binding is present in the cables and wiring

## FOR CUSTOM APPLICATIONS:

1. Disconnect the negative battery terminal
2. Remove all of the handlebar controls
3. Remove the handlebars
4. Install your new Mentele handlebars in the handlebar clamp
5. Guide the switch wires through the bars until the switch housings are fully seated and reassemble the connectors
6. Install the components removed in Step 2
7. Check steering head from right to left lock to ensure no binding is present in the cables and wiring



0601-MENTELE01R1 ©2016 KLOCK WERKS